

Upgrading System Memory

MAG 1500, 2000, 2500, 2600

- Shut down and unplug the unit, then remove the two screws securing the lid and remove.
- Following electro-static discharge precautions, remove the two 1GB memory modules currently in the unit.
- Replace with the two new 2GB memory modules, Crucial part number CT720585.
- Replace lid and secure with screws. Plug the unit back in and press power button.

MAG 2505

- Shut down and unplug the unit, then remove the five screws securing the lid and remove.
- Following electro-static discharge precautions, remove the single 2GB memory module currently in the unit.
- Replace with the two new 2GB memory modules, Crucial part number CT5639905.
- Replace lid and secure with screws. Plug the unit back in and press power button.

MAG 2700 with Dell PE2950 chassis

- Shut down, unplug, and remove the lid.
- Following electro-static discharge precautions, remove the four 512MB memory modules currently in the unit.
- Replace with the two new 4GB memory module using slots 1 and 2. Crucial part number CT553023.
- Replace lid and secure with screws. Plug the unit back in and press power button.

MAG 2700 and MAG2800 with Dell R710 chassis

- Shut down, unplug, and remove the lid.
- Following electro-static discharge precautions, remove the two 1GB memory modules (2700) or the three 1GB memory modules (2800) currently in the unit.
- Replace with the two new 4GB memory module using slots A1 and A2. Crucial part number CT6283932
- Replace lid and secure with screws. Plug the unit back in and press power button.